

GEBRUIKSAANWIJZING HOTELKLUIS

HOTELSAFE INSTRUCTIONS



PROGRAMMEREN VAN UW PERSOONLIJKE CODE

1. Druk de R-toets in met de deur open
2. Kies nu 3 tot 8 nummers als uw persoonlijke code. Bevestig de code door de * in te drukken.
3. Bevestig uw persoonlijke code door deze nogmaals in te geven. Druk vervolgens de * toets in. Een geluid bevestigt de nieuwe code.

OPENEN VAN DE KLUIS

1. Druk de R-toets in gevolgd door uw persoonlijke code, bevestig dit met de * toets.

SLUITEN VAN DE KLUIS

1. Druk de R-toets in gevolgd door de * toets.

Indien u 4x de verkeerde code ingeeft verschijnt er een error op het display. U hoort vervolgens een buzzer voor 1 minuut. U kunt na 1 minuut weer de juiste code invoeren.

PROGRAMMING YOUR PERSONAL CODE

1. Press the R key while the door of the safe is open
2. Choose a code of 3 to 8 digits as your personal code and confirm by pressing *
3. Finally, enter your personal code once more and press * to confirm. You will hear a tone to confirm your code has been registered.

TO OPEN YOUR SAFE

1. Press the R key and enter your personal code. Confirm by pressing * key.

TO CLOSE YOUR SAFE

1. Press the R key followed by pressing * key.

If you would to enter your code incorrectly 4 times, the display will show “error”. Followed by a buzz-tone lasting 1 minute. After this tone you may re-enter your personal code.