

GEBRUIKSAANWIJZING FÖHN

FÖHN INSTRUCTIONS



FÖHN

Op de kamers hebben we twee verschillende type föhns die op twee verschillende manieren aan gaan. Mocht u er niet uitkomen, dan staan onze collega's bij de receptie voor u klaar om te assisteren.

TYPE 1

De föhn werkt zodra u de schakelaar bij binnenkomst van uw hotelkamer omzet. Het knopje boven de föhn dient aan te staan en de stekker dient in het stopcontact te zitten.

TYPE 2

Bij dit type föhn dient u de schakelaar onder de föhn om te zetten en dient u de knop van de föhn aan te zetten, waarna er een rood lampje zal gaan branden.

FÖHN

In the rooms, we have two different types of hair dryers that turn on in two different ways. If you can't figure it out, our colleagues at reception are there to assist you.

TYPE 1

The hair dryer works as soon as you flip the switch upon entering your hotel room. The button above the hair dryer should be on and the plug should be in the socket.

TYPE 2

With this type of hair dryer, you need to flip the switch under the hair dryer and you need to turn on the button of the hair dryer, after which a red light will come on.